



MOTO ARMOR

Can-Am Commander Full Glass Windshield

SKU: MA-COM-GLS-WS

For: Can-Am Commander, Maverick Trail and Sport Models

IMPORTANT: Please read through all instructions before installing. Thank you.

Hardware:

4x – ¼-20 x ⅝" Bolts Blk
2x – ¼-20 x 1" Bolts Blk
2x – ¼-20 Lock Nuts SS
2x – ⅜" Black Spacers
8x – Flat Washers Blk
4x – Lock Washers Blk
4x – Hook clamps Blk
40" – Thick Adhesive Foam



Step One: Remove any roof on the machine and replace after completing all the steps.

Step Two: Place windshield on the machine and thread in the top bolts using the spacers and 1" bolts with washers on both sides and lock nuts. The spacers go between the cage gussets and the windshield.

Step Three: Line up the hook clamps with the holes on the windshield (shown in picture below). Use ⅝" bolts with flat washers and lock washers. Tighten all the bolts.

Do not over tighten the bolts; it may cause glass to break.

Optional step: Use thick adhesive foam to seal any gaps between the windshield and the roof.

