

MOTO ARMOR

Instructions Full Glass CageWRX Race Cage

- 4 – Bolt $\frac{1}{4}$ -20 \times 1/2"
- 4 – Bolt $\frac{1}{4}$ -20 \times 2"
- 4 – Universal Billet Clamp 1.75"
- 4 – Flat Washer 1/4"
- 1 – 1/8" Rubber Trim (50")
- 4 – Thumb knobs with rubber washer 1/2"



STEP ONE – Clip the billet mounts into approximate positions onto roll cage as shown in picture. Use 2" long bolts to hold clamp in place. Only tighten the bolt enough to hold clamp in place but still moveable.

STEP TWO – Place windshield on cage and clamps. Move clamps to line up with holes on windshield frame. Use the 1/2" long bolts and flat washers, (or optional thumb screws for quick removal), to attach frame to billet clamps. (or optional thumb screws for quick removal), to attach frame to billet clamps.

STEP THREE – When windshield is in correct position, tighten the 2" long bolts on the clamps to lock them into position. You can leave the clamps on the roll cage if you take off the windshield to keep the same position when re-installed.