

MOTO ARMOR

Glass Windshield for Kawasaki KRX

Billet Clamps (Black) – 2

1/4" x 2.50" Bolts (BSS) – 2

1/4" x 3/4" Bolts (BSS) – 2

1/4"-20 Lock Nuts (SS) – 2

Lock Washers – 4

1/4" Flat Washers (BSS) – 6

Installation – A Place the billet clamps on the frame in the approximate locations for the lower holes in the windshield. The flat edge of the clamp should be pointing forward and to the middle of the machine. Put the windshield in place and start the 1/4"-20 x 3/4" bolts with a washer in the top two holes. The bolts go through the bracket on the frame. Use washers on both sides and tighten bolts. Using the 2.5" bolts put a lock washer and washer on each bolt before starting it through the clamp. Tighten all bolts.

