

MOTO ARMOR RZR 1000 2 Seat Roof Instructions

Please read through all instructions to get familiar with install before beginning install.

Step 1. Install the spoiler onto the rear of the roof with the 6 small bolts and nuts. Position the spoiler underneath the main roof section. Install the bolts through from the top so that the bolt heads are on top of the roof.

Step 2. Remove the two top factory screws in the visor. Also remove the clip on nuts that were used for those two bolts. Use two of the included ¼" bolts to fasten the roof (loosely) thru the two holes. Use washers on the bolt side, and on the nuts below. Tighten these two bolts so they are a little loose.

Install the rear two bolts through the roof and the factory holes in the roll cage brackets the same as the front.

Make sure the front edge of roof is lined up good with stock visor before beginning to tighten any of the fasteners. Tighten up all of the bolts starting with the first two that were installed thru the visor. Then tighten the rear two bolts.

(For the Fast back spoiler, use the two tube clamps to attach the rear spoiler to the cage before tightening up the rest of the hardware. The fast back spoiler will only install on RZR 1000 XP and Turbo Models)

When mounting on a RZR 900 or RZR 1000s the tube clamps and some of the hardware is not used on the rear spoiler. (a shorter spoiler is supplied instead of the longer spoiler)

Hardware List

(6) ¼-20 x 1.25 Screws

(6) ¼-20 Lock Nuts

(12) ¼" Flat Washers

(6) 10-24 x ½" Black Machine Screws

(6) 10-24 Lock Nuts

(2) Tube Clamps

Check out our site at MOTOARMOR.com for more great products!