

MOTO ARMOR

Glass Windshield for RZR 15', 19', TURBO S

Read through all instructions before install.

4 – Universal Billet Clamp 1.75"

4 – Bolt 1/4-20 x 1/2"

4 – Bolt 1/4-20 x 2"

4 – Flat Washer 1/4"

4 – Thumb knob with
rubber washer 1/2"

4 – Lock Washer



STEP ONE – Clip the billet mounts into approximate positions onto roll cage as shown in picture. Use 2" long bolts to hold clamp in place. Only tighten Bolt enough to hold clamp in place but still moveable.

STEP TWO – Place windshield on cage and clamps. Move clamps to line up with holes on windshield frame. Use the 1/2" long bolts and flat washers, (or optional thumb screws for quick removal), to attach the frame to billet clamps.

STEP THREE – When windshield is in correct position, tighten the 2" long bolts on the clamps to lock them into position. You can leave the clamps on the roll cage if you take off the windshield to keep the same position when re-installed.

Clamp Location

