



Polaris RZR PRO XP 2 Roof Aluminum

1/4"-20 x 3/4" Bolts (BSS) – 8

1/4"-20 Lock Nuts (SS) – 8

1/4" Flat Washers (BSS) – 16

(13 ft.) 1/2 X 1/8" Edge Foam – 1

STEP ONE – Carefully place the roof on its top. Apply the foam to the edge of the roof. Start from an inch from the front corner to the back bend on both outside edges. Optionally you can attach foam to the cross bars. **The adhesive on the foam is very strong, where ever it is placed it will be permanent.**

STEP TWO – Place the roof on the top of the cage lining up each hole. Start the 3/4 " bolts with washers and nuts in each available hole. Beginning tightening the bolts starting at the back making sure to keep the roof centered.

