



Glass Windshield Instructions for RZR PRO XP

SKU: MA-RZPRO-WS (single vent and dual vent) For: RZR PRO XP / RZR TURBO R

Included Hardware

QTY	DESCRIPTION
4	1/4" X 2.5" Bolts (Black SS)
4	1/4" Flat Washers (Black SS)
4	1/4" Lock Washers (Black SS)
4	2" Billet Clamps
1	40" X 1/2" 1/8" Adhesive Foam

!!IMPORTANT!! Read through instructions to become familiar with install before beginning.

Windshield frame and glass should not contact any other accessories that may apply pressure during install or use! (Examples: Mirrors with thick clamps, intrusion bars, accessory clamps.) This type of contact could break glass and is not covered under warranty.

Install windshield wiper on windshield before installation.

(Loosen front of roof if there is a roof on vehicle)

Installation: Slide billet clamps onto roll cage as shown with flat side of the clamp with one hole positioned toward the center of the machine. (The threaded hole on the hump is not used for this installation and should be facing toward the back of the machine.)

With clamps on cage tubes, carefully place windshield on machine. This is much easier with two people. Position windshield under the front of the roof if there is overlap. Use included foam to help minimize rattles between roof and windshield if needed.

Secure windshield in place using one 2.5" bolt with lock washer and flat washer at each clamp. Slide lock washer, then flat washer onto bolt. Then, insert bolt into front of windshield, then through first clamp hole, then into threaded hole in clamp. Wait to tighten any of the bolts till all have been loosely started.

Hand tighten 4 bolts with 5/32" Allen hex wrench.

