



MOTO ARMOR

Honda Talon Glass Windshield Instructions

2 – Rubber Coated Clamps 2" **4** – Locknuts 1/4-20

4 – Bolts 1/4-20 x 1" **8** – Flat Washers 1/4"

STEP ONE – Loosen or remove the roof to begin installation. Slide the tube clamps onto the roll cage in the approximate mounting locations. Put a washer on the bolts before installing them through the windshield frame. Install a washer then a lock nut on the bolt. **CAREFULLY** tighten the 4 bolts and nuts. The clamps have a tendency to pull the windshield frame in further than needed. To counter act this, push on the clamp and nut from the back side so that it is tight against the windshield before tightening. A 7/16" deep socket on a ratchet or drill works great to push the clamp from the back.



Optional – You can also leave the top panel off and bolt only the windsheild onto the machine. Some after market roofs may not fit with the top panel.