



CAN-AM Maverick X3 Rear Window Instructions

Please read through all instructions before beginning installation.

PARTS:

QTY

(1) Main Window

(1) Bottom fill panel

(5) Quick Cinch Straps

Carefully remove film on both sides of window. Take care when handling, installing, and cleaning.

Place window on machine by flexing the window in the middle so you can insert each top corner under the gussets on the rear top corners of the cage.

Secure window by wrapping straps around roll bar and inserting into metal loop then cinching tight.

Straps may come installed through slots in window. If they are not installed, insert each strap with the furry side facing the center (away from the edge) of the window and pull through till the metal loop is tight against the window. These can be installed so that the metal loop is on the inside of the window as well. Just make sure the furry side of the strap is facing away from the edge near each slot.

Install lower panel. To install the lower panel, set it in place from INSIDE the cab. Run the two bottom straps over the top edge then through the holes and out the back. Then loop them around the bar and through the metal rings. Make sure the panel is sitting down against the bed. This helps hold it in place when the straps are tight.



Care and Maintenance:

Polycarbonate is very strong and durable but it can scratch and scuff up easily. Never wipe a dirty window with anything! First spray off with water to remove dust, dirt, mud, or debris of any kind. Then only use a new or newly washed micro fiber towel to lightly dry. Do not push hard as it may scuff. The only cleaner we recommend would be a dusting furniture polish like pledge or similar.