



Pro R 4 Seat Windshield Instructions

Please read through all instructions before installing. Thank you.

Hardware:

2x - 2" Billet Clamps Blk
2x - 1/4-20 x 2.5" Bolts Blk
2x - 1/4-20 x 1" Bolts Blk
2x - 1/4-20 x 5/8" Bolts Blk
4x - 1/4-20 Locknuts SS
2x - Split Lock Washers
10x - Flat Washers Blk
42" - Adhesive Foam



Step 1: Bolt the Windshield attachment to the windshield using the two 1/4-20 x 5/8" bolts with washers on both sides. Circled in green above is where the 1/4-20 x 5/8" bolts go.

Step 2: Slide billet clamps onto the roll cage as shown with the flat side of the clamp with one hole positioned toward the center of the machine. (The threaded hole on the hump is not used for this installation and should be facing toward the back of the machine.)

Step 3: If a roof is on the machine, loosen the front of the roof. Using 2 people put the windshield on the machine. Start the 1" bolts into the top mounting holes. These bolts mount to the cage. Next, use the 2.5" bolts, flat washer, and lock washer to mount the windshield to the billet clamps. Tighten all bolts. **Be cautious not to over tighten the bolts in the billet clamps,** This can cause the windshield to flex and add stress to the glass.



Optional step: Apply adhesive foam to anywhere that the roof contacts the windshield to prevent rattling. Approximate location of foam is in the picture in red.